






Item names/Codes

2710.00502.56	Top Panel
6262.00043.27	Display Panel
2710.00502.29	Back panel
2710.00502.06	Door Group
2710.00502.39	Lower front panel
6214.00013.19	Nut
6214.00001.05	Nut
6262.00011.02	Adjustable feet
2710.00502.490	Door Hinge Left
2710.00502.49	Door Hinge Right
6262.00001.010	Hinge Pin
6213.00002.01	M4x10 Screw
6214.00014.03	Nut
6214.00005.05	Nut
6213.00002.12	M5x20 Screw
2710.F0001.01	Door type Magnet with cover
6262.00001.09	Door Lock Group
6262.00001.081	Door stopper
2710.00502.48	Hinge body
2710.00502.47	lower cover




Item names/Codes

6230.00014.09	CONTACTOR DILEM-10 MOELLER 4 KW
6230.00014.14	CONTACTOR 12-01 MOELLER
6262.00043.17	Power Box
6262.00043.011	Boiler prob
6262.00043.012	Tank prob
6268.00025.15	Pressure switch cable
2710.00502.35	Electrical pano plate ³⁵ / ₄₀
2710.F0001.04	Magnetic Switch
9099.00001.85	Safety Limit Thermostat for washing tank
9099.00001.86	Safety Limit Thermostat for boiler tank
6262.00045.0818	CABLE FOR COVER SENSOR




Item names/Codes

2710.00502.03	Rinsing arm
6262.00033.32	Washing&Rinsing plastic arms
6262.00041.04	Spray arm fixing screw
6262.00041.03	Navel axle
6262.00024.03	Connection Pipe for Bottom Nozzle
6262.00004.040	Gasket
6262.00024.04	Water inlet bottom nut
6262.00021.23	Rinsing hose
6262.00021.12	Water inlet hose
9099.FPD18.0A	Water inlet valve
6262.00021.18	Hose
6226.00010.01	Klinger gasket 1/2"
6262.30666.013	Rinse aid inlet check valve
2710.F0502.00	Boiler tank
9099.01000.01	RESISTANCE 2950 W
6262.00062.08	Tank heater cover




Item names/Codes	
9099.YDK48.2DX	Washing Pump
2710.00502.60	Washing Pump connection plate
6262.00021.081	Hose
6262.00021.082	Hose
6262.00024.03	Connection Pipe for Bottom Nozzle
6226.00004.040	Gasket
6262.00024.04	Water inlet bottom nut
6262.00041.04	Spray arm fixing screw
6262.00033.32	Washing&Rinsing plastic arms
6262.00041.03	Navel axle
6262.00021.07	Hose (pressure switch)
5A1X.37640.615	Pressure Switch
6262.00026.00	Air Trap
6262.00028.06	Drain pipe
6262.00027.04	Suction filter top part
6262.00027.03	Suction filter Nut
6226.00004.16	Suction Filter seal
6262.00027.08	Suction filter lower part
6262.00062.08	Tank heater cover
9099.01000.14	Tank heating resistance
2710.250.01440025.0.01	Heat Transfer Plate
6262.00021.163	Water discharge hose double sided 200cm
6262.00021.092	Drain pump connection hose
9099.P251E.00	Drain pump

DETAIL A




DETAIL B



Item names/Codes

6262.00033.000	Washing arm (without nut&nozzle)
6262.00033.03	Washing arm nozzle
6262.00033.02	Washing arm nut
6262.00005.00	Collector plastic part
6262.00033.200	Rinsing arm (without nut&nozzle)
6262.00033.21	Rinsing arm nozzle
6262.00033.22	Rinsing arm nut
6262.00033.01	Collector (washing&rinsing)
6262.00031.01	Rinsing nozzle top part
6262.00031.00	Rinsing nozzle lower part
6214.00001.01	Nut
6213.00001.01	Screw
6228.00001.01	O-ring

OPTIONAL



2710.50108.B05	Detergent / Rinse aid pump connection plate
6214.00014.03	M4 hex nut with flange
6213.00002.02	M4*16 YHB INOX BOLT
9999.P22CA.030	Rinse aid pump
9740.COD610.A4	Rinse aid pump hose (blue) (4 meters)
6262.00047.03	Spring dosing hose cover
9740.COD13.68	Detergent/Rinse aid pump plastic filter
6262.30666.17	Detergent/Rinse aid pumps tainles steel weight
6238.00003.00	Cable tie
9999.P22AA.010	Detergent pump
9740.COD61.A4	Detergent pump hose (transparent) (4 meters)
9740.COD50.75	Detergent pump tank conexion part
9099.MIDEM.00	Inner Detergent pump tube
9099.MIRIM.00	Inner rinse aid pump tube