







Item names/Codes	
2710.00501.64	Top Panel
6262.00043.27	Display Panel
2710.00501.042	Back panel
2710.00501.005	Door Group
2710.00501.190	Lower front panel
6214.00001.05	Nut
6262.00011.02	Adjustable feet
2710.00502.490	Door Hinge Left
2710.00502.49	Door Hinge Right
6262.00001.01	Hinge Pin
6213.00002.03	M4x20 Screw
6214.00014.03	Nut
6214.00005.05	Nut
6213.00002.12	M5x20 Screw
2710.F0001.01	Door type Magnet with cover
6262.00001.08	Door Lock Group
6262.00001.081	Door stopper
2710.00501.170	Hinge body
2710.00501.571	Lower cover





Item names/Codes


6230.00014.09	Contactor DILEM-10 MOELLER 4 KW
6230.00014.14	Contactor DILEM-12-01 MOELLER
6248.00003.01	Electric inlet terminal
6262.00043.17	Power box
2710.550.42500272.0.04	Electrical pano plate
2710.F0001.04	Magnetic Switch
9099.00001.85	Safety Limit Thermostat for washing tank
6234.00001.21	Safety Limit Thermostat for boiler tank
6268.00025.13	Pressure switch connection cable
6262.00043.011	Boiler tank prob
6262.00043.012	Washing tank prob
6262.00045.0818	CABLE FOR COVER SENSOR





Item names/Codes	
6262.00025.04	Plastic washing elbow (Top)
6226.00004.12	Flat gasket
6262.00025.05	Wash arm support kit mounting pos. Upper nut
6262.00033.33	Washing&Rinsing Arm (Completely) plst.
6262.00024.02	Washing Navel
6226.00004.040	Gasket
6262.00024.04	Water inlet bottom nut
6221.00001.040	CLAMP 40-60MM
6262.00021.30	Washing distribution hose
9099.L80T7.5SX	Washing pump
6221.00001.050	Clamp
6262.00021.101	Hose
6262.00062.08	Washing tank heater cover
9099.01000.14	Washing tank heater
6262.00028.08	drain plug
6262.00027.07	Suction filter top part
6262.00027.06	Suction filter center part
6226.00004.07	Suction filter seal
6262.00027.05	Suction filter lower part
6262.00021.163	Drain hose (for models have drain pump)
6262.00021.76	Drain pump hose
9099.P251E.00	Drain pump
6262.00041.03	Navel axle
6262.00041.04	Screw
6259.00003.043	Cable Gland
6606.00001.12	Grommet rubber Ø8x16
6262.00021.13	Hose
6262.00021.11	Hose







Item names/Codes

6221.00001.020	Clamp
6262.00021.22	Rinsing hose group
5A1X.37640.615	Pressure switch
6262.00021.07	Pressure switch hose
6262.00026.03	Air trap
6226.00006.02	Air tap gasket
6262.00021.12	Water inlet hose
9099.FPD18.0A	Water inlet valve
2710.00500.02	Boiler Body (with heater 3000W)
6262.00021.18	Hose
6262.30666.013	Rinse-aid connection check valve
9099.01000.08	Heater 3000 W (FOR 230V)
9099.01000.05	Heater 5000 W (FOR 400V)
6262.00062.01	Heater cover
9099.R63T3.30	Rinsing pump
6262.00021.18	Rinsing pump hose
2710.00501.69	Rinsing pump housing plate

DETAIL A



A




6262.00033.33

Item names/Codes

6262.00041.04	Screw
6262.00041.03	Shaft
6262.00005.00	Collector plastic part
6262.00033.01	Collector(washing&rinsing)
6262.00033.02	Washing arm nut
6262.00033.03	Washing arm nozzle
6262.00033.00	Washing arm (without nut&nozzle)
6262.00033.20	Rinsing Arm(without nut&nozzle)
6262.00033.21	Rinsing Arm nozzle
6262.00033.22	Rinsing Arm nut
6262.00033.33	Washing&Rinsing Arm (Completely) plst.

OPTIONAL



2710.50108.B05	Detergent / Rinse aid pump connection plate
6214.00014.03	M4 hex nut with flange
6213.00002.02	M4*16 YHB INOX BOLT
9999.P22CA.030	Rinse aid pump
9740.COD610.A4	Rinse aid pump hose (blue) (4 meters)
6262.00047.03	Spring dosing hose cover
9740.COD13.68	Detergent/Rinse aid pump plastic filter
6262.30666.17	Detergent/Rinse aid pumps tainles steel weight
6238.00003.00	Cable tie
9999.P22AA.010	Detergent pump
9740.COD61.A4	Detergent pump hose (transparent) (4 meters)
9740.COD50.75	Detergent pump tank conexion part
9099.MIDEM.00	Inner Detergent pump tube
9099.MIRIM.00	Inner rinse aid pump tube