

























(*) Recommended spare part.

Page	Spare part position	Description	U.m.
1	1	PART NUMBER NO LONGER AVAILABLE	
1	2	LEFT SIDE PANEL	NR
1	3	RIGHT SIDE PANEL	NR
1	4	BACK PANEL	NR
1	5	DOOR SLIDING GUIDE - UPPER FOR POT AND P AN WASHER	NR
1	6	PART NUMBER NO LONGER AVAILABLE	
1	7	PART NUMBER NO LONGER AVAILABLE	
1	8	SUPPORT BRACKET	NR
1	9	DOOR TIE FOR POT AND PAN WASHERS	NR
1	10	DOOR GASKET	NR
1	11	DOOR PACKING SUPPORT - UPPER	NR
1	12	SMALL PLATE FOR DOOR PIN	NR
1	13	RACK SLIDE	NR
1	14	UPPER BUSH FOR DOOR TIE	NR
1	15	PARE-CHOCs HOOD TYPE	NR
1	16	HOOD / DOOR STOP	NR
1	17	LOWER DOOR	NR
1	18	FRONT PANEL	NR
1	19	STAINLESS STEEL SCREW 6MAX30 T.1/2 TC	NR
1	20	UPPER BUSH FOR DOOR TIE FOR POT AND PAN WASHERS	NR
1	21	PART NUMBER NO LONGER AVAILABLE	
1	22	NUT - SELF-LOCK	NR
1	23	FOOT	NR
1	24	BACK PANEL	NR
1	25	MAGNETIC DOOR SWITCH	NR
1	26	DOOR BRACKET	NR
1	30	UPPER BUSH FOR DOOR TIE	NR
1	31	DOOR SIDE THICKNESS - DX/SX	NR
2	1	COVER	NR
2	2	SEAL	NR
2	3	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 228010)	
2	3	FUSE	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
2	4	ELECTRICAL CONNECTOR FOR U-SHAPED BAR	NR
2	5	TERMINAL BLOCK	NR
2	6	TERMINAL	NR
2	7	TERMINAL	NR
2	8	FUSE-HOLDER	NR
2	9	PART NUMBER NO LONGER AVAILABLE	
2	11	CONTACTOR	NR
2	12	CONTACTOR	NR
2	14	PANEL	NR
2	15	FOOT	NR
2	16	MAIN BOARD GET50.2 ELETTRONICA J	NR
2	17	TERMINAL BLOCK	NR
2	18	POWER CABLE	NR
2	19	CABLE GLAND	NR
2	20	FUSE	NR
2	21	FLAT CABLE	NR
2	22	CONTROL KEYBOARD	NR
2	23	NUT	NR
2	24	INTERFACE BOARD DISTANCE KEEPERS	NR
2	25	CONTROL ADHESIVE INTERFACE POT WASHER MAXIMA	NR
2	27	CURTAIN	NR
2	30	BUSH	NR
2	31	BUSH	NR
2	32	BUSH	NR
2	33	HOSE CLAMP	NR
3	1	TANK STRAINER BASKET	NR
3	2	STAINER	NR
3	3	PUMP ASPIRATION FILTER	NR
3	4	ASPIRATION FILTER SLIDE	NR
3	5	WASHER	NR
3	6	PRESSURE SWITCH	NR
3	7	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 423028)	

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
3	7	HOSE CLAMP	NR
3	8	PIPE	MT
3	10	AIR TRAP FOR PRESSURE SWITCH	NR
3	11	GASKET	NR
3	12	NUT	NR
3	13	SUPPORT TEMPERATURE PROBE	NR
3	14	TEMPERATURE PROBE	NR
3	15	HEATING ELEMENT	NR
3	16	O-RING	NR
3	17	BOILER HEATING ELEMENT PROTECTION	NR
3	19	SAFETY THERMOSTAT (95) L=1500MM	NR
3	20	STAINLESS STEEL BASIC RACK	NR
3	21	KIT RACK SLIDING BLOCKS	NR
3	22	DOSING PUMP	NR
3	23	DETERGENT DOSING PUMP	NR
3	24	HOSE	NR
3	25	"SANTOPRENE" PIPE	NR
3	26	SUPPORT BRACKET	NR
3	27	LINEN RUBBER PIPE 5X12 - BLACK	MT
3	28	PIPE	MT
3	29	PIPE	MT
3	30	DETERGENT TANK FITTING	NR
3	31	FILTER AID DISPENSER	NR
3	32	WIRING	NR
3	36	PLUG	NR
3	37	HOSE PLUG	NR
4	1	SLEEVE	NR
4	2	HOSE CLAMP	NR
4	3	PIPE FITTING	NR
4	4	GASKET	NR
4	5	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 80285)	
4	5	RING NUT	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
4	6	INOX RING	NR
4	7	RING NUT	NR
4	8	PIPE FITTING	NR
4	9	CLAMP, TORRO W1/W2B 50-70/12	NR
4	10	PIPE	NR
4	12	WASHPUMP	NR
4	13	SUCTION PIPE	NR
4	14	CLAMP, HOSE-TYPE TORRO W2B 60-80/12	NR
4	16	SUCTION PIPE	NR
4	17	SUPPORT BRACKET	NR
4	18	OVERFLOW PIPE	NR
4	19	O-RING	NR
4	20	STAINER	NR
4	21	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 429038)	
4	21	RING NUT	NR
4	22	O-RING	NR
4	23	ASPIRATION AND DRAIN BODY	NR
4	24	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 423034)	
4	24	HOSE CLAMP	NR
4	25	DRAIN HOSE	NR
4	30	SEAL DAMPENS VIBRATIONS	NR
4	31	SCREW	NR
4	32	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 417087)	
4	32	NUT	NR
5	1	BOILER	NR
5	2	NON-RETURN VALVE	NR
5	11	BOILER BRACKET	NR
5	14	PIPE	MT
5	16	SOLENOID VALVE	NR
5	17	GASKET	NR
5	18	INLET HOSE	NR
5	19	TEMPERATURE PROBE	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
5	20	SUPPORT TEMPERATURE PROBE	NR
5	21	HEATING ELEMENT 6KW	NR
5	22	THERMOSTAT 110 C 67878 + BRACKET	NR
5	23	BOILER HEATING ELEMENT PROTECTION	NR
5	25	PIPE FITTING	NR
5	26	O-RING	NR
5	32	JUNCTION "Y"	NR
5	34	PIPE FITTING	NR
5	35	HOSE CLAMP	NR
5	44	PIPE	NR
6	1	PIVOT	NR
6	2	WASHER	NR
6	3	RING NUT	NR
6	4	RINSE AND WASH ARM	NR
7	1	DRAIN PUMP FILTER	NR
7	2	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 429038)	
7	2	RING NUT	NR
7	3	O-RING	NR
7	4	ASPIRATION AND DRAIN BODY	NR
7	7	PUMP ASPIRATION SLEEVE	NR
7	8	DRAIN PUMP90- V 220/240- F50	NR
7	10	DRAIN HOSE	NR
7	11	DRAIN CONNECTION	NR
7	12	DRAIN HOSE	NR
7	13	SUPPORT BRACKET	NR
7	14	VENT VALVE	NR
7	15	GASKET	NR
7	16	SPHERE	NR
7	17	PIPE FITTING	NR
7	18	SP2 VENT VALVE	NR
7	19	DRAIN HOSE	NR
7	20	HOSE CLAMP	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
7	21	HOSE CLAMP	NR
7	22	PART NUMBER NO LONGER AVAILABLE (PART NR. REPLACED BY 423034)	
7	22	HOSE CLAMP	NR
7	23	BRACKET	NR
7	25	HOSE CLAMP	NR
8	1	WASHPUMP	NR
8	3	ELECTROPUMP FAN COVER	NR
8	4	WASHPUMP FUN	NR
8	5	PART NUMBER NO LONGER AVAILABLE	
8	6	WASHPUMP SHAFT SEAL	NR
8	7	O-RING	NR
8	8	ELECTROPUMP IMPELLER	NR
8	9	ELECTROPUMP HOUSING	NR