


















(*) Recommended spare part.

Page	Spare part position	Description	U.m.
1	1	PART NUMBER NO LONGER AVAILABLE	
1	2	BACK PANEL	NR
1	3	SUPPORT BRACKET	NR
1	4	DOOR GASKET 50/505	NR
1	5	DOOR LOCK FOR DISHWASHERS	NR
1	6	DOOR CLOSING CONTACT BETA 50 (S6198)	NR
1	7	NUT OF TOP DOOR-STOP BAR	NR
1	8	DOOR	NR
1	9	DOOR CLOSURE STAKE FOR GLASSWASHERS	NR
1	10	DOOR BRACKET	NR
1	11	PIVOT	NR
1	12	DOOR TIE ROD FOR DISHWASHER (S6323)	NR
1	13	WIRING PANEL	NR
1	14	FRONT PANEL	NR
1	15	PART NUMBER NO LONGER AVAILABLE	
1	16	BASE FRAME LA600	NR
1	17	HEXAGONAL FOOT ADJUSTABLE FOR DISHWASHER	NR
1	18	PLUG	NR
1	19	CHOCK D INT 9 EST 16	NR
1	20	DRAIN PUMP CHOCK	NR
1	30	PLUG	NR
1	34	SPRING LA600 L=66MM	NR
1	35	FIXING PLATE	NR
1	36	FIXING PLATE	NR
1	37	PIVOT	NR
1	45	PART NUMBER NO LONGER AVAILABLE	
1	46	PART NUMBER NO LONGER AVAILABLE	
2	1	PRESSURE SWITCH	NR
2	4	PIPE	MT
2	5	TERMINAL BLOCK	NR
2	6	CABLE H07RN-F 5X2.5X2.5MT	NR
2	7	CABLE-RETAINER	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
2	8	HEATING ELEMENT 2100W 230V	NR
2	9	PACKING OF THE TANK RESISTANCE	NR
2	10	SAFETY TANK THERMOSTAT 95C	NR
2	11	THERMOSTAT 127	NR
2	12	O-RING	NR
2	13	HEATING ELEMENT	NR
2	14	BOILER HEATING ELEMENT PROTECTION	NR
2	15	PROBE HOLDER	NR
2	16	FIXING PLATE	NR
2	17	TEMPERATURE PROBE	NR
2	18	MAGNETIC DOOR SWITCH	NR
2	19	TRANSPARENT PROTECTION FOR ELECTRIC INSTALLATION FOR DISHWASHER	NR
2	20	FILTER AID DISPENSER	NR
2	21	PIPE	MT
2	22	"SANTOPRENE" PIPE	NR
2	23	DETERGENT DOSING PUMP	NR
2	24	DETERGENT TANK FITTING	NR
2	25	WATER LEVEL CONTROL	NR
2	26	PACKING FOR AIR TRAP OF PRESSURE SWITCH	NR
2	27	O-RING	NR
2	28	AIR TRAP CONNECTION OF PRESSURE SWITCH	NR
2	30	CONTROL ADHESIVE INTERFACE MAXIMA DISHWASHER	NR
2	31	FLAT WIRE	NR
2	32	PUSH BUTTONS ASSEMBLY	NR
2	33	NUT	NR
2	34	INTERFACE BOARD DISTANCE KEEPERS	NR
2	35	MAIN BOARD GET50.2	NR
2	36	FUSE	NR
2	39	CONTACTOR 230V GMC-9M/4 50/60HZ	NR
2	40	FOOT BOARD SUPPORT	NR
2	49	PVC CURTAIN FOR ELECTRIC PROTECTION	NR
2	54	GROUP STOPPED TANK HEATER	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
2	58	THERMOSTAT 90+/-3C	NR
3	1	PART NUMBER NO LONGER AVAILABLE	
3	2	NO RETURN VALVE	NR
3	3	PIPE	MT
3	4	GASKET	NR
3	5	FILL VALVE	NR
3	6	BOILER	NR
3	7	ASPIRATION AND DRAIN BODY	NR
3	8	DELIVERY WASH HOSE	NR
3	9	O-RING	NR
3	10	DELIVERY WASH HOSE	NR
3	11	MAINFOLD	NR
3	12	GASKET	NR
3	13	RING NUT	NR
3	14	STAINER	NR
3	15	O-RING	NR
3	16	OVERFLOW PIPE	NR
3	17	MAINFOLD	NR
3	18	DELIVERY HOSE	NR
3	20	DOSING PUMP	NR
3	21	HOSE	NR
3	22	LINEN RUBBER PIPE 5X12 - BLACK	MT
3	23	PIPE	MT
3	24	FILTER AID DISPENSER	NR
3	25	DRAIN HOSE	NR
3	26	INLET WRAS PIPE	NR
3	27	GASKET	NR
3	28	SUPPORT ARMS WASH / RINSE	NR
3	29	GASKET	NR
3	30	PIPE	MT
3	31	RING NUT	NR
3	36	PIVOT	NR

(*) Recommended spare part.

Page	Spare part position	Description	U.m.
4	1	RING NUT	NR
4	2	RING	NR
4	3	PIVOT	NR
4	4	RINSE AND WASH ARM	NR
4	5	WASHER	NR
4	6	RING NUT	NR
4	7	RINSE AND WASH ARM	NR
4	13	RING NUT	NR
4	14	GASKET	NR
4	15	MAINFOLD	NR
4	16	STAINER	NR
4	17	CENTRAL CROSS ARM FOR SPRING HOOKING	NR
5	1	WASHING UNIT LA600 50HZ	NR
5	3	WASHPUMP SHAFT SEAL	NR
5	4	WASHPUMP SHAFT SEAL	NR
5	5	ELECTROPUMP IMPELLER 73048 (3235)	NR
5	6	O-RING	NR
5	7	RING NUT	NR
5	8	ELECTROPUMP HOUSING	NR
5	9	PLUG	NR
5	10	CAPACITOR	NR