




PART LIST

S/N	Description (English)
1	Decoration facial of crumb tray
2	Crumb tray
3	Guiding net
4	Driving shaft
5	Net
6	Baffle board
7	Left support of heating elements
8	Left board of chamber
9	Front cross beam
10	Bottom board of chamber
11	Indicator
12	Facial
13	Rheostat
14	Knob
15	Fan
16	Switch
17	Compartment board of bottom board
18	Bottom board
19	Fix base for front shaft sleeve
20	Motor
21	Motor sprocket
22	Right board
23	Base board for heating elements
24	Support for heating elements

25	Lower heating elements
26	Adjustable foot
27	Driving sprocket
28	Screw
29	Nut
30	Fix base for rear shaft
31	Shaft sleeve
32	Right board of chamber
33	Chain
34	Nail
35	Rear crumb tray
36	Rear board
37	Rear runner board
38	Spring clip
39	Lower runner board
40	Duct board
41	Nut
42	Lid for heating elements
43	Terminal
44	Power cord
45	Left board
46	Top board of chamber
47	Screw
48	Compartment board of top board
49	Top board
50	Screw
51	Upper heating element