




BH30 PART LIST							
NO.	PART NAME	SPECIFICATION	QTY	NO.	PART NAME	SPECIFICATION	QTY
1	Logo		1	44	Base	B20E-04-08-01	1
2	Cross Recess Head Screw	M5x16	4	45	Inner Gear	B20F-01-26a	1
3	Front Cover	B20E-04-04	1	46	Soket Head Cap Screw	M6x30	6
4	Top Box	B30B-04-03	1	47	Micro Switch	Z-15GW22	1
5	Control Panel	B30B-04-05	1	48	Cross Recess Head Screw	M4×25	2
6	Star Button		1	49	Side Cover	B20E-05-01	1
7	Stop Button		1	50	Shield Block	B20K-05-02-01	1
8	Countersunk Decorative Cover	B7LB-01-17	1	51	Safety Cover	B20K-05-02-02	1
9	Cross Recess Head Screw	M6×35	1	52	Nut	M10	1
10	TOP Cover	B20K-04-01	1	53	Spring Washer	10	1
11	Cross Recess Head Screw	M5×10	4	54	Flat Washer	10	1
12	Biaxial Bearing Cap	B20K-04-17	1	55	Bearing	6201	1
13	Cross Recess Head Screw	M6×10	3	56	Input Shaft	B20K-01-03	1
14	Single Bearing Cap	B20K-04-16	1	57	Flat Key	A5x15	1
15	Bearing Oil Hole Cover	B20F-04-18	2	58	Worm Gear	B20K-01-01-02	1
16	Soket Head Cap Screw	M6x20	4	59	Bearing	6201	1
17	Spring Washer	6	4	60	Nut	M10	1
18	Flat Washer	6	4	61	Spring Washer	10	1
19	Bearing Base	B20K-04-15	1	62	Flat Washer	10	1
20	Shaft Circlip	16	2	63	Bearing	6201	1
21	Motor Worm	B20K-01-01-01	1	64	Bridge Shaft	B20K-01-04	1
22	Skeleton Oil Seal	SG29×52×8	1	65	Flat Key	A5x15	1
23	Bearing	6203	1	66	Bridge Shaft Big Gear	B20K-01-06	1
24	Motor Rotor	B30B-01-01-04	1	67	Intermediate Bridge Of Shaft Sleeve	B20K-01-07	1
25	Flat Key	A3×25	1	68	Flat Key	A5x15	1
26	Motor Stator	B30B-01-01-05	1	69	Bridge Shaft Small Gear	B20K-01-05	1
27	Bearing	6203	1	70	Bearing	6201	1
28	Centrifugal Switch		1	71	Nut	M12	1
29	Motor Cap	B20K-01-01-03a	1	72	Spring Washer	12	1
30	Soket Head Cap Screw	M6×20	4	73	Flat Washer	12	1
31	Fan Blade		1	74	Bearing	6203	1
32	Back Cover	B20E-04-20	1	75	Ratchet Upper Cover	B20K-01-10a	1
33	Cross Recess Head Screw	M4×10	4	76	Inner Star Wheel	B20K-01-11	1
34	Lift Marked		1	77	Roller	B20K-01-12	6
35	Micro Switch	SN7311	1	78	Roller Compression Spring	B20F-01-13a	6
36	Travel Switch Box	B20K-05-04	1	79	Outer Ring	B20K-01-14	1
37	Electrical Box	B20K-05-05	1	80	Ratchet Lower Cover	B20K-01-15a	1
38	Working Capacitor		1	81	Upper Clutch	B20K-01-17	1
39	Start-Up Capacitor		1	82	Gear Sleeve Of Output Shaft	B20K-01-18	1
40	Electric Lid	B20K-05-06	1	83	Clutch Of Output Shaft	B20K-01-19	1
41	Overload Protector		1	84	Output Shaft	B20K-01-09	1
42	Power Cord Jacket		1	85	Flat Key	A6x30	1
43	Main Shaft	B30B-04-06-YS	1	86	Flat Key	A6x32	2

BH30 PART LIST							
NO.	PART NAME	SPECIFICATION	QTY	NO.	PART NAME	SPECIFICATION	QTY
87	Flat Key	A6x40	1	121	Shift Fork	B20F-03-09	1
88	Gear Sleeve Of Output Shaft	B20K-01-18	1	122	Flat Washer	10	1
89	Lower Clutch	B20K-01-20	1	123	Spring Washer	10	1
90	Bearing Upper Sleeve	B20K-01-21	1	124	Nut	M10	1
91	Bearing	6205	1	125	Nut For Shift Fork	B20F-03-12	2
92	Shaft Circlip	25	1	127	Top Pin For Shift Fork	B10K-03-10	2
93	Oil Seal	25×52×7	1	128	Bowl	B30K-04-14	1
94	Transposition	B20F-01-23b	1	129	Beater	B30C-01-28	1
95	Flat Washer	16	1	130	Hook	B30C-01-29	1
96	Spring Washer	16	1	131	Whip	B30C-01-27-00	1
97	Nut	M16	1	132	Hexagon Socket Flat Point Set Screws	M12×60	1
98	Nut	M12	1	133	Hexagon Nut	M12	1
99	Flat Washer	12	1	134	Hexagon Bolt	M6×20	6
100	Planetary Gear	B20F-01-24	1	135	Spring Washer	6	6
101	Bearing	6203	1	136	Flat Washer	6	6
102	Planetary Shaft	30C-01-25a	1	137	Travel Switch Block Slice	B20K-05-03	1
103	Flat Key	A5x18	1	138	Press Plate	B20K-04-13	2
104	Straight Pin	8x30	1	139	Bowl Base	B30K-04-09	1
105	Bearing	6005	1	140	Soket Head Cap Screw	M8×25	2
106	Bearing	6005	1	141	Bowl Locker Handle	B20K-04-11	2
107	Handle Ball	M8	1	142	Spring Washer	8	2
108	Shifting Handle	B20K-03-01a	1	143	Hexagon Nut	M8	2
109	Shifting Handle Holder	B20K-03-02a	1	144	Bowl Spport	B20K-04-10	2
110	Elastic Straight Pin	4×30	1	145	Spring Washer	8	2
111	Variable Speed Core Shaft	B20F-03-03a	1	146	Nut	8	2
112	O Type Of Ring	9×1.8	1	147	Lifting Handle	B30B-02-21	1
113	Hexagon Bolt	M6×16	4	148	Flat Washer	10	1
114	Shifting Base	B20K-03-04	1	149	Arm Drag	B20E-02-23	1
115	O Type Of Ring	37.5×2.65	1	150	Elastic Straight Pin	5x26	1
116	Spring For Location	B20F-03-06	2	151	Cotter Pin	4x20	1
117	Steel Ball	B20F-03-05	2	152	Connecting Rod	B30B-02-24	1
118	Eccentric Bushing	B20F-03-07	1	153	Hexagon Bolt	M10	3
119	Elastic Straight Pin	4×22	1	154	Large Flat Washer	10	3
120	Shift Fork Guide	B20K-03-08	1	155	Spring	B20L-02-04	1