

NO	ITEM	QTY /PCS
1	Electric head back plate	1
2	Electric head	1
3	Handle of Electric head	2
4	Timer Knob	1
5	Timer	1
6	Power switch	1
7	Micro switch	1
8	Temperature Limiter	1
9	Temperature Limiter Knob	1
10	Indicator	1
11	Thermostat Knob	1
12	Thermostat dial	1
13	Thermostat	1
14	Cable Lock	1
15	Power cord	1
16	MAX-MIN Level	1
17	Heater Fixed board	1
18	Heater	1
19	Rubber Feet	4
20	Oil Valve	1
21	Oil valve cap	1
22	oil filler plate	1
23	Heater cover	1
24	Cover	1
25	Cover handle	1
26	Fryer basket	1
27	Machine's body	1
28	Relay	1
29	Terminal	1
30	Terminal	1

