




No	Item	QTY/pcs
1	Cover	1
2	Heater fixed board	2
3	Spin Axis	1
4	Upper hotplate fixed part	1
5	Upper hotplate fixed board	1
6	Upper hotplate	1
7	Handle	1
8	Lower hotplate	1
9	Upper Heating Element	1
10	Lower Heating Element	1
11	Lower hotplate fixed board	1
12	Lower Cover	1
13	Backboard	1
14	Lower hotplate fixed part	1
15	Hotplate supporting shelf	1
16	Timer	1
17	Timer knob	1
18	Power indicator	1
19	Heat indicator	1
20	Power Switch	1
21	Thermostat	1
22	Thermostat Dial	1
23	Thermostat Knob	1
24	Backboard	1
25	Base body	1
26	Cable locker	1
27	baseplate	1
28	Rubber Feet	4
29	Cable	1