

11	Heater	3	26	AC contactor	1
12	Level board	1	27	Microswitch	1
13	Pressure plate of heater	1	28	Timer knob	1
14	Electric box	1	29	Switch	1
15	Thermostat	1	30	Basket support plate	1