


EXPLODED VIEW - MAXIMA HOT DISPLAY 186L - 09400795



PARTS LIST - MAXIMA HOT DISPLAY 186L - 09400795

- | | |
|------------------------------------|------------------------------------|
| 1. Power Cable | 27. Clamp |
| 2. Base Casing | 28. Nut |
| 3. Control Panel | 29. Glass Sliding Door 1 |
| 4. Heater Casing Bracket | 30. Glass Door Frame |
| 5. Heater Casing | 31. Advertising Box Side Cover (L) |
| 6. Heating Element | 32. Door Handle |
| 7. Heater Cover | 33. Glass Sliding Door 2 |
| 8. Water Reservoir | 34. Glass Door Frame |
| 9. Base Cover | 35. Socket |
| 10. Front Sliding Slot | 36. Upper Shelf Bracket (L) |
| 11. Back Sliding Slot | 37. Upper Shelf Bracket (R) |
| 12. Bottom Shelf | 38. Middle Shelf Bracket (L) |
| 13. Middle Shelf | 39. Middle Shelf Bracket (R) |
| 14. Upper Shelf | 40. Bottom Shelf Bracket (L) |
| 15. LED Mount (R) | 41. Bottom Shelf Bracket (R) |
| 16. LED Mount (L) | 42. Foot |
| 17. LED Cover (R) | 43. Temperature Display |
| 18. LED Cover (L) | 44. Indicator Light |
| 19. Frame | 45. Switch |
| 20. Top Cover | 46. Temperature Controller |
| 21. Small Top Fence (L) | 47. Thermostat 1 |
| 22. LED Light | 48. Thermostat 2 |
| 23. Illuminated Advertising Box | 49. Socket Connector |
| 24. Advertising Box Side Cover (R) | 50. Lower Side Window Gasket (R) |
| 25. Side Window | 51. Lower Side Window Gasket (L) |
| 26. LED Light | 52. Small Top Fence (R) |